

SPREADING BATH OIL

INGREDIENT	% By Weight
I	
ADOL 66	7.0
Mineral Oil	45.0
STARFOL OS	45.0
II	
AROSURF 66-PE12	1.0
Perfume	2.0
III	
Preservative	qs

Mixing Instructions:

Mix Phase I ingredients. Add pre-mixed Phase II to Phase I.

Solids: 98.0%

SOURCE: Sherex Chemical Co.: Formulation Code 6.2.4

THREE LAYER BATH OIL WITH PROTEIN

RAW MATERIALS	% By Weight
Mineral Oil	32.00
PPG-50 Cetyl Ether (Procetyl 50)	32.00
Water	31.00
Hydrolyzed Animal Protein (Crotein SPC)	4.00
Perfume	q.s.
GERMABEN II	1.00
Color - suggested one per layer	q.s.

Procedure:

Dissolve the protein in water with the GERMABEN II and a water soluble D & C Color. Add color to the PPG-50 Cetyl Ether, add color to the mineral oil. Blend all 3 phases.

On shaking the product will mix and may be poured into the bath in this form. On settling, it reseparates into the attractive three layers.

SOURCE: Sutton Laboratories, Inc.: Sutton Cosmetic Formulary - Supplement #1