

MAKE-UP BASE CC-100

RAW MATERIALS	% By Weight
Part A:	
Lanaetex 75	3.00
Myristyl Myristate	2.20
Diethyl Sebacate	2.00
Dispersen G	2.00
Brij 56	0.10
Butyl Paraben	0.10
Part B:	
Water	68.25
Veegum HV	0.50
Keltrol	0.15
Glycerin	3.00
Citric Acid	0.30
Germaben II	0.60
Methyl Paraben	0.10
Part C:	
SS-4267	3.00
SF-1214	1.00
Talc	5.00
Titanium Dioxide	5.00
Iron Oxide	3.70

Procedure:

- 1) Heat Part A and Part B to 75C.
- 2) Add Part B to Part A with high shear mixing.
- 3) Cool to 55C and add Part C with good mixing.
- 4) Continue mixing until cooled to 75C.

SOURCE: GE Silicones: Personal Care Formulary: Formulation
CC-100

MOISTURE MAKE-UP

RAW MATERIALS	% By Weight
Part A:	
SCHERCOMID AME-70	20.0
SCHERCEMOL MM	20.0
Promulgen D	5.0
Part B:	
Powder Mixture	5.0
Part C:	
Carbowax 400	10.0
Micro Crystalline Cellulose	40.0
Fragrance, preservative	qs

SOURCE: Scher Chemicals, Inc.: SCHERCOMID AME-70: Formulation
SG-0208