

MILD FACIAL CLEANSER

RAW MATERIALS	% By Weight
MIRANOL 2MHT Modified	20.0
MIRATAINE COB	10.0
Witconate AOS	15.0
Cedepon LA 30HV	10.0
Cedemide CX	2.0
Cerasynt IP	1.0
Water	42.0

## Procedure:

Mix all ingredients except water and Cedepon LA 30HV together and heat to 60C to dissolve the Cerasynt IP. Add water and Cedepon LA 30HV. Adjust pH to 6.5 with citric acid.

Solids: 25.0%, viscosity: 3800 cps.

MILD FACIAL CLEANSER

RAW MATERIALS	% By Weight
MIRANOL 2MHT Modified	20.0
MIRANOL 2MCAS Modified	15.0
MIRATAINE COB	10.0
Cedemide CX	1.0
Water	54.0

## Procedure:

Mix all ingredients together and agitate until uniform. Adjust pH to 7.0 with citric acid.

Solids: 22.0%, viscosity: 1000 cps.

SKIN CLEANSER

RAW MATERIALS	% By Weight
MIRANOL CS Conc.	20.0
MIRATAINE COB	10.0
CEDEPON LS 30PM	15.0
Cedemide CX	1.0
Ajidew N-50	1.0
Water	53.0

## Procedure:

Mix all ingredients together and heat to 60C to dissolve the Cedemide CX. Adjust pH to 7.0 with citric acid.

Solids: 18.5%, viscosity: 1500 cps.

SOURCE: Miranol Inc.: MIRANOL Products for Cosmetics and Toiletries: Suggested Formulations